

# Multi-Port GSM Gateway Series

Automatic Recharge Service



**AddPac**

**AddPac Technology**

2012, Sales and Marketing

[www.addpac.com](http://www.addpac.com)

# Contents

- Automatic Recharge Service





# Automatic Recharge Service

# [WEB] Auto Recharge (1/2)

## Mobile USSD

Balance checking USSD String :   Send Send Time :  (sec)

Recharging USSD string :

Set Port Group / Time  (Port Group)  (ms)

Auto Recharge :  Enable Thresold Amount :  Balance check time per day :   hour

Balance keyword:  Recharge keyword:

### Manual Recharge

<input type="checkbox"/>	Port	Mode	Data Code	USSD Reply	Reply Date
--------------------------	------	------	-----------	------------	------------

#### Auto Recharge Global Option

- If the auto-recharge service feature is enabled, balance will be recharged automatically.

\* check condition : below threshold amount

\* check time : configured hour a day

\* balance parsing keyword :

ex) balance check reply message "Balance:926.3 BDT Exp:01-01-00,Bought Minutes:0.00 Exp:01-01-70,Bonus(Mins:0.00,SMS:0.)" "  
balance keyword = "Balance:" parsed balance = 926

\* recharge parsing keyword

ex) recharge reply message "BDT 1,226.3 Exp dt:01-01-00" "  
recharge keyword = "BDT" parsed balance = 1226

# [WEB] Auto Recharge (2/2)

## Mobile USSD

Balance checking USSD String:   Send Send Time:  (sec)

Recharging USSD string:  Save

Set Port Group / Time  (Port Group)  (ms)

Auto Recharge:  Enable Threshold Amount:  Balance check time per day:  hour Apply

Balance keyword:  Recharge keyword:

Manual Recharge					
<input type="checkbox"/>	Port	Mode	Data Code	USSD Reply	Reply Date
<input type="checkbox"/>	P0:0	<input checked="" type="radio"/> Balance <input type="radio"/> Recharging	<input type="text"/>	<input checked="" type="checkbox"/> Send	-
<input type="checkbox"/>	P0:1				
<input type="checkbox"/>	P0:2				
<input type="checkbox"/>	P0:3	<input checked="" type="radio"/> Balance <input type="radio"/> Recharging	<input type="text"/>	<input checked="" type="checkbox"/> Send	-

**Auto Recharge Specific Port Option**

- If the port option for auto-balance-recharge is configured, the configured global option will be ignored.
- All options are same to global option.
- Display the configured global options .

Auto Recharge								
Port	Enable	Threshold Amount	BalanceCheckTime(Hour)	Parsing keyword		USSD code		Control
				Balance	Recharge	Balance	Recharge	
Global	Disable	-1	-1					
P0:0	Global <input type="text" value="v"/>	<input type="text" value="-1"/>	<input type="text" value="0"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input checked="" type="checkbox"/> Apply

# GSM Gateway Series

# Thank you!

**AddPac Technology Co., Ltd.**  
Sales and Marketing

Phone +82.2.568.3848 (KOREA)

FAX +82.2.568.3847 (KOREA)

E-mail [sales@addpac.com](mailto:sales@addpac.com)